

# ANT130 R Hardware Manual

Revision: 1.06.00



#### **Global Technical Support**

Go to www.aerotech.com/global-technical-support for information and support about your Aerotech products. To get help immediately, contact a service office or your sales representative (Support@aerotech.com). Include your customer order number in your email.

**Software Support**: Aerotech offers a range of software packages readily available for download. Free software is available for instant download. Chargeable software requires a current software key. Link: Software Downloads

**Software Activation**: The following link provides information and resources to activate your Aerotech software. Link: Software Activation

Manuals, Help Files, and Cable Drawings: Browse a directory of manuals, help files, and cable drawings for Aerotech software and hardware products. Link: Browse Manuals, Help Files, and Cable Drawings

**Frequently Asked Questions**: The Frequently Asked Questions (FAQs) section provides answers to most common questions about Aerotech products. Link: Product FAQs

Product Training: View training information and schedule a training class. Link: Training Sessions

**Request Product Repair or Return**: We offer complete service and repair services for all of our products. Learn more about our pricing and warranties, plus access the forms required for many Global Technical Support port requests. Link: Repair & Return

Remote and Field Service Technical Support: Schedule a remote session now or a field service appointment. Link: Remote Technical Support

This manual contains proprietary information and may not be reproduced, disclosed, or used in whole or in part without the express written permission of Aerotech, Inc. Product names mentioned herein are used for identification purposes only and may be trademarks of their respective companies.

Copyright © 2010-2021, Aerotech, Inc., All rights reserved.





## Table of Contents

ANT130R Hardware Manual Table of Contents List of Figures	<b>1</b> 3 4
Elist of Tables	
Chapter 1: Overview 1.1. Environmental Specifications 1.2. Accuracy and Temperature Effects 1.3. Basic Specifications	9 
Chapter 2: Mechanical Specifications and Installation 2.1. Unpacking and Handling the Stage 2.2. Dimensions 2.3. Securing the Stage to the Mounting Surface 2.4. Attaching the Payload to the Stage	<b>13</b> 13 14 14 16 17
Chapter 3: Electrical Specifications and Installation 3.1. Motor and Feedback Connectors 3.2. Motor and Feedback Wiring 3.3. Motor and Feedback Specifications 3.4. Limits, Marker, and Machine Direction 3.5. Motor and Feedback Phasing	<b>19</b> 20 22 23 23 25 26
Chapter 3: Electrical Specifications and Installation 3.1. Motor and Feedback Connectors 3.2. Motor and Feedback Wiring 3.3. Motor and Feedback Specifications 3.4. Limits, Marker, and Machine Direction 3.5. Motor and Feedback Phasing Chapter 4: Maintenance 4.1. Service and Inspection Schedule 4.2. Cleaning and Lubrication 4.3. Troubleshooting	
Chapter 3: Electrical Specifications and Installation 3.1. Motor and Feedback Connectors 3.2. Motor and Feedback Wiring 3.3. Motor and Feedback Specifications 3.4. Limits, Marker, and Machine Direction 3.5. Motor and Feedback Phasing Chapter 4: Maintenance 4.1. Service and Inspection Schedule 4.2. Cleaning and Lubrication 4.3. Troubleshooting Appendix A: Warranty and Field Service	
Chapter 3: Electrical Specifications and Installation 3.1. Motor and Feedback Connectors 3.2. Motor and Feedback Wiring 3.3. Motor and Feedback Specifications 3.4. Limits, Marker, and Machine Direction 3.5. Motor and Feedback Phasing Chapter 4: Maintenance 4.1. Service and Inspection Schedule 4.2. Cleaning and Lubrication 4.3. Troubleshooting Appendix A: Warranty and Field Service Appendix B: Revision History	

## List of Figures

Figure 2-1:	ANT130R Dimensions	14
Figure 2-2:	ANT130R Mounting Plate (-MP) Dimensions	15
Figure 2-3:	Mounting Hole Pattern	16
Figure 2-4:	Load Orientations	18
Figure 2-5:	Cantilevered Load Capabilities	18
Figure 3-1:	Motor and Feedback Wiring	22
Figure 3-2:	Machine Direction	25
Figure 3-3:	Hall Phasing	26
Figure 3-4:	Analog Encoder Phasing Reference Diagram	27
Figure 3-5:	Encoder Phasing Reference Diagram (Standard)	27

## List of Tables

Table 1-1:	ANT130R Model Numbering System	9
Table 1-2:	Environmental Specifications	10
Table 1-3:	ANT130R Series Specifications	11
Table 2-1:	Stage to Mounting Surface Hardware	16
Table 3-1:	Motor and Feedback Pinouts	21
Table 3-2:	Feedback Specifications	23
Table 3-3:	Motor Specifications	24
Table 3-4:	Encoder Resolution	24

## Safety Procedures and Warnings

This manual tells you how to carefully and correctly use and operate the ANT130R.

- Read all parts of this manual before you install or operate the ANT130R or before you do maintenance to your system.
- To prevent injury to you and damage to the equipment, obey the precautions in this manual.
- Aerotech continually improves its product offerings; listed options may be superseded at any time. All drawings and illustrations are for reference only and were complete and accurate as of this manual's release. Refer to www.aerotech.com for the most up-to-date information.

If you do not understand the information in this manual, contact AerotechGlobal Technical Support.

**DAN GER**: This product contains potentially lethal voltages. To reduce the possibility of electrical shock, bodily injury, or death the following precautions must be followed.

- 1. Access to the ANT130R and component parts must be restricted while connected to a power source.
- 2. Do not connect or disconnect any electrical components or connecting cables while connected to a power source.
- 3. Moving parts can cause crushing or shearing injuries. Access to all stage and motor parts must be restricted while connected to a power source.
- 4. Disconnect electrical power before servicing equipment.
- 5. All components must be properly grounded in accordance with local electrical safety requirements.
- 6. Operator safeguarding requirements must be addressed during final integration of the product.

**WARNING**: To prevent damage to the equipment and to decrease the risk of electric shock and injury, obey the precautions that follow.

- 1. Cables can pose a tripping hazard. Securely mount and position all system cables to avoid potential hazards.
- 2. Do not expose this product to environments or conditions outside of the listed specifications. Exceeding environmental or operating specifications can cause damage to the equipment.
- 3. The ANT130R stage actuator unit must be mounted securely. Improper mounting can result in injury and damage to the equipment.
- 4. Use care when moving the ANT130R stage actuator unit. Lifting or transporting the ANT130R stage actuator unit improperly can result in injury or damage to the ANT130R.
- 5. If the product is used in a manner not specified by the manufacturer, the protection provided by the product can be impaired and result in damage, shock, injury, or death.
- 6. Operators must be trained before operating this equipment.
- 7. All service and maintenance must be performed by qualified personnel.



#### **EU Declaration of Incorporation**

	Aerotech, Inc.
Manufacturary	101 Zeta Drive
Manufacturer:	Pittsburgh, PA 15238-2811
	USA

#### herewith declares that the product:

ANT130R Stage

*is intended to be incorporated into machinery to constitute machinery covered by the Directive 2006/42/EC as amended;* 

and that the following harmonized European standards have been applied:

#### EN ISO 12100:2010

Safety of machinery - Basic concepts, general principles for design EN 60204-1:2010

Safety of machinery - Electrical equipment of machines - Part 1: General requirements

#### and further more declares that

it is not allowed to put the equipment into service until the machinery into which it is to be incorporated or of which it is to be a component has been found and declared to be in conformity with the provisions of the Directive 2006/42/EC and with national implementing legislation, for example, as a whole, including the equipment referred to in this Declaration.

This is to certify that the aforementioned product is in accordance with the applicable requirements of the following Directive(s):

EU 2015/863	Directive, Restricted Substances (RoHS3)
Authorized Representative:	Smon Smith, European Director Aerotech Ltd
Address:	The Old Brick Kiln, Ramsdell, Tadley
	Hampshire RG26 5PR
	UK
	on

Name Position Location Date allow Mith entry / Alex Weibel

Engineer Verifying Compliance Pittsburgh, PA 4/12/2021

CE

This page intentionally left blank.

## Chapter 1: Overview

**IM PORTANT**: Aerotech continually improves its product offerings, and listed options may be superseded at any time. Refer to the most recent edition of the Aerotech Motion Control Product Guide for the most current product information at www.aerotech.com.

#### Table 1-1: ANT130R Model Numbering System

ANT130R Single-Axis Rotary Direct-Drive Nanopositioning Stage			
Travel (Required)			
-360	Continuous travel		
-020	Limited travel ±10 degrees		
-180	Limited travel ±90 degrees		
Mounting Plate (Optional)			
-MP	Breadboard mounting plate		
Performance Grade (Required)			
-PL1	Base performance		
-PL2	High-accuracy performance		

## **1.1. Environmental Specifications**



**WARNING**: Do not expose this product to environments or conditions outside of the listed specifications. Exceeding environmental or operating specifications can cause damage to the equipment.

Table 1-2:	Environmental	Specifications
		opeonications

	Operating: 10° to 35° C (50° to 95° F)
Ambient	The optimal operating temperature is $20^{\circ}$ C $\pm 2^{\circ}$ C (68° F $\pm 4^{\circ}$ F). If at any time the
Temperature	occur.
	Storage: 0° to 40° C (32° to 104° F) in original shipping packaging
	Operating: 20% to 60% RH
Humidity	Storage: 10% to 70% RH, non-condensing in original packaging. The stage should be packaged with desiccant if it is to be stored for an extended time.
	Operating: 0 m to 2,000 m (0 ft to 6,562 ft) above sea level
Altitude	Contact Aerotech if your specific application involves use above 2,000 m or below sea level.
	Use the system in a low vibration environment. Excessive floor or acoustical
Vibration	your specific application.
Protection	The ANT130R stages are not suited for dusty or wet environments. This equates to
Rating	an ingress protection rating of IP00.
Use	Indoor use only

#### 1.2. Accuracy and Temperature Effects

Aerotech products are designed for and built in a 20°C (68°F) environment. Extreme temperature changes could cause a decrease in performance or permanent damage to the ANT130R. At a minimum, the environmental temperature must be controlled to within 0.25°C per 24 hours to ensure the ANT130R specifications are repeatable over an extended period of time. The severity of temperature effects on all specifications depends on many different environmental conditions, including how the ANT130R is mounted. Contact the factory for more details.

The accuracy specification of ANT130R series stages is measured 25 mm above the table with the stage in an unloaded condition. The stage is assumed to be fully supported by a mounting surface meeting or exceeding the specification in Section 2.3.

## **1.3. Basic Specifications**

Resolution is dependent on encoder resolution and controller interpolation.

 Table 1-3:
 ANT130R Series Specifications

		-20	-180	-360
Rotation Angle		20°	180°	±360° Continuous
Accuracy <sup>(1)</sup>	-PL1	10 arc sec	10 arc sec	10 arc sec
	-PL2	3 arc sec	3 arc sec	3 arc sec
Resolution (Minimum	Incremental Motion)	0.01 arc sec	0.01 arc sec	0.01 arc sec
Bidirectional Repeata	ability <sup>(1)</sup>	1.5 arc sec	1.5 arc sec	1.5 arc sec
Unidirectional Repeat	tability	0.5 arc sec	0.5 arc sec	0.5 arc sec
Tilt Error Motion	Synch	Not applicable	Not applicable	10 arc sec
	Asynch	Not applicable	Not applicable	3 arc sec
Avial Error Motion <sup>(1)</sup>	Synch	Not applicable	Not applicable	2 μm
	Asynch	Not applicable	Not applicable	0.5 μm
Radial Error Motion	Synch	Not applicable	Not applicable	3 μm
(1)	Asynch	Not applicable	Not applicable	1 μm
Maximum Speed		20 rpm	20 rpm	200 rpm
Maximum Acceleration		400 rad/s <sup>2</sup>	400 rad/s <sup>2</sup>	400 rad/s <sup>2</sup>
In-Position Stability <sup>(2)</sup>		0.005 arc sec	0.005 arc sec	0.005 arc sec
Aperture		11 mm	11 mm	11 mm
Maximum Torque (Continuous)		0.2 N⋅m	0.2 N·m	0.2 N⋅m
	Axial	3.0 kg (6.6 lb)	3.0 kg (6.6 lb)	3.0 kg (6.6 lb)
Load Capacity <sup>(3)</sup>	Radial	2.0 kg (4.4 lb)	2.0 kg (4.4 lb)	2.0 kg (4.4 lb)
	Moment	3 N∙m	3 N∙m	3 N·m
Rotor Inertia (Unloaded)		0.001 kg·m <sup>2</sup>	0.001 kg·m <sup>2</sup>	0.0016 kg⋅m²
Stage Mass		1.5 kg (3.3 lb)	1.5 kg (3.3 lb)	1.7 kg (3.74 lb)
Material	Aluminum Body/Black Hardcoat Finish			
Mean Time Between Failure	30,000 Hours			

2. In-Position Jtter listing is 3 sigma value.

3. Axis orientation for on-axis loading is listed (refer to Section 2.4. for offset loading behavior).

Specifications are for single-axis systems measured 25 mm above the tabletop; performance of multi-axis system is payload and workpoint dependent. Consult the Aerotech factory for multi-axis or non-standard applications.
All error motion specifications are measured at 60 rpm.

• For high speed operation, customer payload must be balanced to G1.0 per ISO 1940.

This page intentionally left blank.

## Chapter 2: Mechanical Specifications and Installation



**WARNING**: The ANT130R must be installed according to the instructions in this manual and any accompanying documentation. Failure to follow these instructions could result in injury or damage to the equipment.

## 2.1. Unpacking and Handling the Stage

**WARNING**: Manually lifting and moving the stage requires a minimum of two people on either side of the stage. Refer to Section 1.3. for stage mass specifications.

- Do not attempt to lift heavy loads single handed.
- Follow the lifting instructions and only manually lift from the specified surfaces (if lifting hardware hasn't been supplied).
- Do not use any of the cables as lifting points.

WARNING: It is the customer's responsibility to safely and carefully lift the stage.

- Make sure that all moving parts are secure before moving the ANT130R. Unsecured moving parts may shift and cause bodily injury.
- Improper handling could adversely affect the performance of the ANT130R. Use care when moving the ANT130R.



**IM PORTANT**: If any damage has occurred during shipping, report it immediately.

Carefully remove the ANT130R from its protective shipping container. Gently set the ANT130R on a smooth, flat, and clean surface.

Before operating the ANT130R, it is important to let it stabilize at room temperature for at least 12 hours. Allowing it to stabilize to room temperature will ensure that all of the alignments, preloads, and tolerances are the same as they were when tested at Aerotech. Use compressed nitrogen or clean, dry, oil-free air to remove any dust or debris that has collected during shipping.

Each ANT130R has a label listing the system part number and serial number. These numbers contain information necessary for maintaining or updating system hardware and software. Locate this label and record the information for later reference.

### 2.2. Dimensions



Figure 2-1: ANT130R Dimensions



Figure 2-2: ANT130R Mounting Plate (-MP) Dimensions

## 2.3. Securing the Stage to the Mounting Surface

**WARNING**: The ANT130R must be mounted securely. Improper mounting can result in injury or damage to the equipment.

The mounting surface must be flat and have adequate stiffness to achieve the maximum performance from the ANT130R stage. When it is mounted to a non-flat surface, the stage can be distorted while the mounting screws are tightened. This distortion will decrease overall accuracy. Adjustments to the mounting surface must be done before the stage is secured.

Inspect the mounting surface for dirt or unwanted residue and clean if necessary. Use precision flatstones on the mounting surface to remove any burrs or high spots. Clean the mounting surface with a lint-free cloth and acetone or isopropyl alcohol and allow the cleaning solvent to completely dry. Gently place the stage on the mounting surface.

IM PORTANT: To maintain accuracy, the mounting surface must be flat to within 1  $\mu m$  per 50 mm.



**IM PORTANT**: The ANT130R is precision machined and verified for flatness prior to product assembly at the factory. If machining is required to achieve the desired flatness, it should be performed on the mounting surface rather than the ANT130R. Shimming should be avoided if possible. If shimming is required, it should be minimized to retain maximum rigidity of the system.

ANT130R series stages have a fixed mounting pattern (as shown in Figure 2-3).

Tightening torque values for the mounting hardware are dependent on the properties of the surface to which the stage is being mounted. Values provided in Table are typical values and may not be accurate for your mounting surface.

#### Table 2-1: Stage to Mounting Surface Hardware

Mounting Hardware	Typical Screw Torque
M6 SHCS	4.6 N⋅m



Figure 2-3: Mounting Hole Pattern

## 2.4. Attaching the Payload to the Stage

Inspect the mounting surface for dirt or unwanted residue and clean if necessary. Clean the mounting surface with a lint-free doth and acetone or isopropyl alcohol and allow the cleaning solvent to completely dry.

Aerotech recommends that customers use a representative payload during start-up to prevent accidental damage to the stage and the payload. Proceed with the electrical installation and test the motion control system in accordance with the system documentation. Document all results for future reference. For information on electrical installation refer to Electrical Specifications and Installation and the documentation delivered with the stage.



**IMPORTANT**: If your ANT130R was purchased with Aerotech controls, it might have been tuned with a representative payload based on the information provided at the time of order. If the ANT130R is started up without a payload, the servo gains provided by Aerotech with the shipment may not be appropriate and servo instability can occur. Refer to the controller help file for tuning assistance.

The payload must be flat, rigid, and comparable to the stage in quality to maintain optimum performance.



**IM PORTANT**: If possible, use 3-point mounting when you attach the payload to the stage.



 $\mbox{IMPORTANT}:$  For valid system performance, the mounting interface should be flat within 1  $\mu m$  per 50 mm.



**WARNING**: Refer to the dimensions in Section 2.2. for maximum allowable thread engagement. A screw extending through the stage table can affect travel and damage the stage.

Applied loads should be symmetrically distributed whenever possible (i.e., the payload should be centered on the stage table and the entire stage should be centered on the support structure).

If cantilevered loads are applied, refer to Figure 2-4 to find the loading condition. Refer to Figure 2-5 to find the maximum allowable load.



## Chapter 3: Electrical Specifications and Installation



**IM PORTANT**: Electrical installation must be performed by qualified personnel only.

Aerotech motion control systems are adjusted at the factory for optimum performance. When the ANT130R is part of a complete Aerotech motion control system, setup usually involves connecting the ANT130R to the appropriate drive chassis with the cables provided. Labels on the system components usually indicate the appropriate connections.

If system level integration was purchased, an electrical drawing showing system interconnects has been supplied with the system (separate from this documentation).

The electrical wiring from the motor and encoder are integrated at the factory. Refer to the sections that follow for standard motor wiring and connector pinouts.



**DANGER**: Remove power before connecting or disconnection electrical components. Failure to do so can cause electric shock or damage to the equipment.



**DANGER**: Access to the base and tabletop must be restricted while connected to a power source. Failure to do so can cause electric shock or other bodily harm.



**IM PORTANT**: Refer to the controller documentation to adjust servo gains for optimum velocity and position stability.



**IM PORTANT**: The ANT95R does not have Hall sensor signals. The controller has to initialize motor commutation through the use of a software algorithm.

## 3.1. Motor and Feedback Connectors

Stages equipped with standard motors and encoders come from the factory completely wired and assembled.

The protective ground connection of the ANT130R provides motor frame ground protection only. Additional grounding and safety precautions are required for applications requiring access to the stage while it is energized. The System Integrator or qualified installer is responsible for determining and meeting all safety and compliance requirements necessary for the integration of this stage into the final application.



**DANGER**: The protective ground connection must be properly installed to minimize the possibility of electric shock.



**DANGER**: The stage controller must provide over-current and over-speed protection. Failure to do so could cause electric shock or damage to the equipment.

Pin	Description	Connector
1	Key (Ensures that correct cable is plugged into the correct jack)	
2	Cosine-N	
3	Sine-N	
4	Marker-N	
5	Common ground <sup>1</sup>	
6	Common ground <sup>1,3</sup>	
7	Negative (CCW) hardware limit <sup>2</sup>	
10	Frame Ground	o 2
11	Motor Phase A	0
12	Motor Phase B	° 🙆
13	Motor Phase C	
14	Cosine	
15	Sine	0
16	Marker	• • • • •
17	+5 V supply input for feedback devices	
18	Reserved	
19	Positive (CW) hardware limit <sup>2</sup>	25 13
20	Motor Thermistor	
22	Signal shield connection	
23	Motor Phase A	
24	Motor Phase B	
25	Motor Phase C	
Case	Signal shield connection (to case)	
1. Pins	5 and 6 are only jumpered on stages with limits (ANT130R-020 and ANT130R-180)	
2. Limit	pins 7 and 19 are reserved on ANT130R-360	
3. Pin 6	is reserved on ANT130R-360	

Table 3-1:	M ot or	and	Feedback	Pinouts
------------	---------	-----	----------	---------

Mating Connector	Aerotech P/N	Third Party P/N
Backshell	ECK00656	Amphenol #17E-1726-2
Connector	ECK00300	FCI DB25S064TLF

## 3.2. Motor and Feedback Wiring

All motor and controller manufacturers have their own designations for motor ØA/ØB/ØC (refer to for motor phasing). Shielded cables are required for the motor and feedback connections.



 $\mathbb{A}$ 

Limit pins 7 and 19 are reserved (not used) on the ANT130R-360.

Pin 6 is reserved (not used) on the ANT130R-360.

Figure 3-1: Motor and Feedback Wiring

#### 3.3. Motor and Feedback Specifications

#### Table 3-2: Feedback Specifications

Thermistor Specifications		
Polarity	Logic "0" (no fault)	
	Logic "1" (over-temperature fault)	
Cold Resistance	~100 Ω	
Hot Resistance	~10 K	
Note: 1K pull-up to +5V recommended.		

Encoder Specifications			
Supply Voltage	5 V ±5%		
Supply Current	250 mA max		
Output Signals	<b>Sinusoidal Type (Incremental Encoder)</b> : 1 $V_{pk-pk}$ into 120 $\Omega$ Load (differential signals SIN+, SIN-, COS+, COS- are .5 $V_{pk-pk}$ relative to ground.)		

Limit Switch Specifications [Not available on the ANT130R-360]			
Supply Voltage	5 V		
Supply Current	25 mA		
Output Type	Open Collector		
Output Voltage	5 V		
Output Current	10 mA (sinking)		
	Normally Closed (NC)		
	Sinks current to ground (Logic "0") when not in limit		
Output Polarity	High impedance (Logic "1") when in limit		
	<ul> <li>Requires external pull-up to +5 V (10 kΩ recommended)</li> </ul>		
Notes:	·		

• If the ANT130R is driven beyond the electrical limit, it will encounter a mechanical stop. Impacting the mechanical stop could cause damage to the stage even at low speeds.

#### Table 3-3: Motor Specifications

		SF-75-21-2X <sup>(2)</sup>
		[AN T130R]
Performance Specifications <sup>(1,6)</sup>		
Stall Torque, Continuous	N-m (oz-in)	0.27 (38.4)
Peak Torque <sup>(4)</sup>	N-m (oz-in)	1.08 (153.6)
Rated Power Output, Continuous	watts	113.6
Electrical Specifications <sup>(6)</sup>		
Winding Designation		-В
BEMF Constant (Line to Line, Max)	Voltspk/krpm	10.9
Continuous Current, Stall	Amppk (Amprms)	3.00 (2.12)
Peak Current, Stall <sup>(4)</sup>	Amppk (Amprms)	12.00 (8.49)
Torque Constant <sup>(5,7)</sup>	N-m/Amppk (oz-in/Amppk)	0.09 (12.8)
	N-m/Amprms (oz-in/Amprms)	0.13 (18.1)
Motor Constant <sup>(5)</sup>	N/√₩ (lb/√₩)	0.042 (5.92)
Resistance, 25°C (Line to Line)	ohms	4.8
Inductance (Line to Line)	mH	0.45
Maximum Bus Voltage	VDC	80
Thermal Resistance	°C/W	1.78
Number of Poles	Р	8
1. Performance is dependent upon heat sir	k configuration, system cooling conditions, a	and ambient temperature

2. Values shown @ 68°C rise above a 25 °C ambient temperature, with housed motor mounted to a 250 mm x 250 mm x

6 mm aluminum heat sink

4. Peak torque assumes correct rms current; consult Aerotech

5. Torque constant and motor constant specified at stall

6. All performance and electrical specifications  $\pm 10\%$ 

7. All Aerotech amplifiers are rated  $A_{Pk}$ ; use torque constant in N·m/A<sub>Pk</sub> when sizing

#### Table 3-4: Encoder Resolution

Model	AN T130R-020	AN T130R-180	AN T130R-360
Fundamental Resolution		18000 Lines / Rev	
With x4000 Interpolation		0.0180 arcsec	
With x16000 Interpolation	0.0045 arcsec		
1. Quadrature decoding included in interpolation resolution calculations.			

### 3.4. Limits, Marker, and Machine Direction

Aerotech stages are configured to have positive and negative "machine" directions. The machine direction defines the phasing of the feedback and motor signals and is dictated by the stage wiring (refer to Section 3.5. for Motor and Feedback phasing information). Programming direction of a stage is set by the controller that is used to move the stage. Programming direction is typically selectable in the controller, while machine direction is hardwired in the stage. Figure 3-2 shows the machine direction of ANT130R stages.





## 3.5. Motor and Feedback Phasing

Motor phase voltage is measured relative to the virtual wye common point.





This page intentionally left blank.

## Chapter 4: Maintenance

**IM PORTANT**: If the bearing area is not kept free of foreign matter and moisture, the performance and life expectancy of the stage will be reduced.



**DAN GER**: To minimize the possibility of bodily injury or death, disconnect all electrical power prior to performing any maintenance or making adjustments to the equipment.

## 4.1. Service and Inspection Schedule

Inspect the ANT130R at least once per month. A longer or shorter inspection interval may be required depending on the application and conditions, such as the duty cycle, speed, and environment.

In general, stages operating in a clean environment should be cleaned annually. For stages operating under conditions involving excessive debris, stages should be cleaned every six months. In normal operating conditions and with proper cleanliness of the stage, the bearing will not require lubrication or maintenance for the life of the stage.

Monthly inspections should include but not be limited to:

- Visually inspect the stage and cables.
- Re-tighten loose connectors.
- Replace or repair damaged cables.
- Clean the ANT130R and any components and cables as needed.
- Repair any damage before operating the ANT130R.
- Inspect and perform an operational check on all safeguards and protective devices.

## 4.2. Cleaning and Lubrication

**DAN GER**: To minimize the possibility of bodily injury or death, disconnect all electrical power prior to performing any maintenance or making adjustments to the equipment.



**IM PORTANT**: In applications that have multiple stages bolted together to form multi-axis systems, the orthogonality may be lost if the stage tables of the support stages are loosened. Precision aligned stages should not be loosened or disassembled.



**IM PORTANT**: Further disassembly of the stage is not recommended because proper assembly and calibration can only be done at the factory. In addition, a laser interferometer is required for post assembly verification to maintain warranties. Contact Aerotech for more information.

#### Cleaning

Before using a cleaning solvent on any part of the ANT130R, blow away small particles and dust with nitrogen or, less preferably, clean, dry, compressed air.

Any external metal surface of the ANT130R can be cleaned with isopropyl alcohol on a lint-free doth.



WARNING: Make sure that all solvent is completely dry before you move the stage.

#### Lubrication

There are no elements on ANT130R stages that require lubrication.

If the application process uses only a small portion of travel for most of the duty cycle, periodically drive the stage through full travel to redistribute the lubrication in the bearings.

## 4.3. Troubleshooting

Symptom	Possible Cause and Solution
Stage will not move	<ul> <li>Shipping restraints still installed. Remove the red anodized shipping brackets.</li> <li>In Limit condition. Check limits (refer to Electrical Specifications and Installation) and refer to the Controller documentation for polarity and compatibility requirements (Example: voltage requirements).</li> <li>Controller trap or fault (refer to the Controller documentation).</li> </ul>
Stage moves uncontrollably	<ul> <li>Encoder (sine and cosine) signal connections (refer to Electrical Specifications and Installation and Controller documentation).</li> <li>Motor Connections (refer to Electrical Specifications and Installation and the Controller documentation).</li> </ul>
Stage oscillates or squeals	<ul> <li>Gains misadjusted (refer to the Controller documentation).</li> <li>Encoder signals (refer to the Controller documentation).</li> </ul>

This page intentionally left blank.

## Appendix A: Warranty and Field Service

Aerotech, Inc. warrants its products to be free from harmful defects caused by faulty materials or poor workmanship for a minimum period of one year from date of shipment from Aerotech. Aerotech's liability is limited to replacing, repairing or issuing credit, at its option, for any products that are returned by the original purchaser during the warranty period. Aerotech makes no warranty that its products are fit for the use or purpose to which they may be put by the buyer, whether or not such use or purpose has been disclosed to Aerotech in specifications or drawings previously or subsequently provided, or whether or not Aerotech's products are specifically designed and/or manufactured for buyer's use or purpose. Aerotech's liability on any daim for loss or damage arising out of the sale, resale, or use of any of its products shall in no event exceed the selling price of the unit.

THE EXPRESS WARRANTY SET FORTH HEREIN IS IN LIEU OF AND EXCLUDES ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, BY OPERATION OF LAW OR OTHERWISE. IN NO EVENT SHALL AEROTECH BE LIABLE FOR CONSEQUENTIAL OR SPECIAL DAMAGES.

#### Return Products Procedure

Claims for shipment damage (evident or concealed) must be filed with the carrier by the buyer. Aerotech must be notified within thirty (30) days of shipment of incorrect material. No product may be returned, whether in warranty or out of warranty, without first obtaining approval from Aerotech. No credit will be given nor repairs made for products returned without such approval. A "Return Materials Authorization (RMA)" number must accompany any returned product(s). The RMA number may be obtained by calling an Aerotech service center or by submitting the appropriate request available on our website (www.aerotech.com). Products must be returned, prepaid, to an Aerotech service center (no C.O.D. or Collect Freight accepted). The status of any product returned later than thirty (30) days after the issuance of a return authorization number will be subject to review.

Visit https://www.aerotech.com/global-technical-support.aspx for the location of your nearest Aerotech Service center.

#### **Returned Product Warranty Determination**

After Aerotech's examination, warranty or out-of-warranty status will be determined. If upon Aerotech's examination a warranted defect exists, then the product(s) will be repaired at no charge and shipped, prepaid, back to the buyer. If the buyer desires an expedited method of return, the product(s) will be shipped collect. Warranty repairs do not extend the original warranty period.

**Fixed Fee Repairs** - Products having fixed-fee pricing will require a valid purchase order or credit card particulars before any service work can begin.

All Other Repairs - After Aerotech's evaluation, the buyer shall be notified of the repair cost. At such time the buyer must issue a valid purchase order to cover the cost of the repair and freight, or authorize the product(s) to be shipped back as is, at the buyer's expense. Failure to obtain a purchase order number or approval within thirty (30) days of notification will result in the product(s) being returned as is, at the buyer's expense.

Repair work is warranted for ninety (90) days from date of shipment. Replacement components are warranted for one year from date of shipment.

#### Rush Service

At times, the buyer may desire to expedite a repair. Regardless of warranty or out-of-warranty status, the buyer must issue a valid purchase order to cover the added rush service cost. Rush service is subject to Aerotech's approval.

#### On-site Warranty Repair

If an Aerotech product cannot be made functional by telephone assistance or by sending and having the customer install replacement parts, and cannot be returned to the Aerotech service center for repair, and if Aerotech determines the problem could be warranty-related, then the following policy applies:

Aerotech will provide an on-site Field Service Representative in a reasonable amount of time, provided that the customer issues a valid purchase order to Aerotech covering all transportation and subsistence costs. For warranty field repairs, the customer will not be charged for the cost of labor and material. If service is rendered at times other than normal work periods, then special rates apply.

If during the on-site repair it is determined the problem is not warranty related, then the terms and conditions stated in the following "On-Site Non-Warranty Repair" section apply.

#### On-site Non-Warranty Repair

If any Aerotech product cannot be made functional by telephone assistance or purchased replacement parts, and cannot be returned to the Aerotech service center for repair, then the following field service policy applies:

Aerotech will provide an on-site Field Service Representative in a reasonable amount of time, provided that the customer issues a valid purchase order to Aerotech covering all transportation and subsistence costs and the prevailing labor cost, including travel time, necessary to complete the repair.

#### Service Locations

http://www.aerotech.com/contact-sales.aspx?mapState=showMap

## Appendix B: Revision History

Revision	General Information
1.06.00	Updated encoder specs
	Product update
1.05.00	Safety information updated
	General revision
1.04.00	Added -PL2 option
	Updated motor specifications
1.03.00	Added Environmental Specifications section
	Added safety information and warnings
	<ul> <li>Added note about current requirements of motor and ground wires</li> </ul>
1.02.00	Updated motor specifications
1.01.00	Updated load capacities
	Updated basic specifications
1.00.00	New manual

This page intentionally left blank.

Index			
		lubrication	30
		Lubrication	30
2		lubrication schedule	29
2006/42/EC	7	М	
А		mounting surface	
Appleration	44	cleaning	16
Acceleration	11	securing stage	16
Ambient Temperature	10	multiaxis combinations	30
	10	0	
С		•	
cleaning		orthogonality	30
mounting surface	16	Р	
solvents	30	•	
Cleaning	30	part number	13
		Protection Rating	10
D		protective ground connection	20
Directive 2006/42/EC	7	S	
Е		serial number	13
EN 00004 4 0040	7	service schedule	29
EN 60204-1 2010	7	shimming	16
EN ISO 12100 2010	/	solvents	30
Encoder Specifications	23	Speed	11
EU 2015/863	7	stabilizing stage	13
0		stage	
G		distortion	16
Global Technical Support	2	stabilizing	13
		Support	2
Н			
Humidity	10	Т	
		Technical Support	2
I		Thermistor Specifications	23
inspection schedule	29	Torque	11
Inspection Schedule	29		
isopropyl alcohol	30	V	
		Vibration	10
L			
label	13	W	
Limit Switch Specifications	23	Warranty and Field Service	33

This page intentionally left blank.